

Instructions for Your Digital Watch



Buttons

- LIGHT
- MODE
- START
- RESET

Screen order (tap **MODE**)

From normal time display, tap **MODE** to cycle:

1. **Stopwatch**
2. **Alarm**
3. **Time Setting**

Quick views

- Hold **START** = shows **Date**.
- Hold **RESET** = shows **Alarm time**.

Light

- Press **LIGHT** once = turn on backlight.
- Hold **LIGHT** for **3 seconds** = change backlight color.

Set Time + Calendar

1. From normal time, tap **MODE** until you see the time and **seconds are blinking**.
2. Tap **RESET** to move through fields in this exact order:

Seconds → Minutes → Hours → Date (Day of Month) → Month → Day of Week

3. Press **START** to change the blinking value.
4. Press **MODE** to **exit/save**.

Swap 12-hour ↔ Military Time

1. Tap **MODE** until you see the time with seconds blinking.
2. Tap **RESET** until you reach Hours (seconds → minutes → hours).
3. Press **START** to advance the hour.
Keep pressing and it will cycle: 12-hour (AM/PM) → 24-hour (military) → back to 12-hour.
4. Press **MODE** to **exit/save**.

Set Alarm Time

1. Tap **MODE** twice to reach the **Alarm** screen.
2. Set **Hour**.
3. Tap **MODE** once.
4. Set **Minute**.
5. Press **MODE** to exit/save.

Alarm ON/OFF

1. Hold **RESET**.
2. While holding **RESET**, tap **START**.
3. The **((.))** icon is the alarm indicator:
 - **((.)) showing** = Alarm ON
 - **((.)) gone** = Alarm OFF

Hourly Chime ON/OFF

1. Hold **RESET**.
2. While holding **RESET**, tap **START**.
3. Listen during the button press:
 - **No beep** = Chime OFF
 - **Beep** = Chime ON

Note: Alarm toggle and Chime toggle are the same physical action.

- Icon tells you Alarm state.
- Beep/no-beep tells you Chime state.

Stopwatch

1. Tap **MODE** once to reach Stopwatch.
2. **START** = start/stop
3. **RESET** = clear