


Quick Start Guide

T25

Active Noise Cancelling
Wireless Earbuds

This quick start guide will support you getting started using your device. If you're looking for a more detailed user manual, FAQs, and other information, please visit our official website.




CHARGING


1

Charge Earbuds

Before using the earbuds, please put the earbuds into the charging case, close the lid and let the earbuds charge for about 10 minutes.




Charge Charging Case




POWERING ON/OFF

2



ON

Open the charging case.



OFF



Put the earbuds back into the charging case and close the lid.

PAIRING





















1 Turn on the Bluetooth of your phone.

2 Open the charging case (LED indicator flashes red and white alternately).



3 Choose "T25" to pair.

BUTTON CONTROLS

	  L/R	  L	  R	Volume -  L	Volume +  R
	  L/R	  L/R	Voice Control  L		
	 R	<p>Transparency Mode</p>  <p>ANC OFF ANC ON</p>			


x1: Single tap

x3: Triple tap

x2: Double tap

⌚2": Hold for 2 seconds.

⌚3": Hold for 3 seconds.



⏻ ON: ○ 1"

🔗 PAIRING: ◐

🔋 LOW BATTERY: ●

●●● 4" 66%-100% battery

●●○ 4" 33%-66% battery

●○○ 4" 5%-33% battery

●-○○ ×4 Low battery

○ : LED indicator stays white.

◐ : LED indicator flashes red and white alternately.

● : LED indicator flashes red.