


SIMILAR TO WHAT'S
**SEEN ON
TV**

Gadgets **and** More Electric Arc BBQ Lighter

This product uses a lithium-ion rechargeable battery. The booster assembly raises the low voltage of 3.7V to high voltage of 7KV with a frequency of around 15kHz. This high frequency and high voltage generates an electric arc by ionizing the air between two electrodes, which is then used to ignite materials like candles, gas stoves, charcoal grills dry leaves or other combustible materials.

DIRECTIONS

- Connect the charger with an output voltage of 5V \pm 0.5V and output current below 3000mAh such as computer or mobile phone charge through USB port for charging.
- Connect the charger, then disconnect and reconnect the charger when using for the first time or when not having used it for a long time.
- Built-in smart charging circuit indicator light will light up at the bottom of the product when charging, and the light turns off automatically after fully charged.
- Please disconnect the power immediately after fully charged. Product will be fully charged after 1 to 2 hours. Do not leave the fully charged battery connected to a power source. Overcharging will shorten battery life.
- This battery is rechargeable and can be discharged hundreds of times on a single charge. Charging immediately after use, before the battery is fully discharged, will extend the battery life.
- For safety reasons, this product is equipped with multiple safety functions such as overcharging, over discharging, and overloading. If the heating time is too long, the product will automatically cut off the internal power supply and lock the circuit, making the product unusable.
- This product will automatically shut down after being ignited for 7 seconds to avoid affecting the usage time due to long-term use.



WARNING



Please follow the safety rules below:

- Do not pierce this product with sharp objects.
- Do not burn this product in a fire, and keep away from open flames and temperatures above 120°F/50°C. Do not place in direct sunlight, otherwise it may cause a fire and shorten the life of the product.
- Keep this product out of the reach of children.
- Do not disassemble this product.
- Do not submerge in water or other liquids, otherwise it will cause product to short circuit.
- Do not use this product with any other charger than the enclosed charging cord. Otherwise it may cause a short circuit or cause the product to overheat, making it unusable.
- To avoid burns to the skin and shorten the product life, do not use this product more than 5 times continuously.
- When using this product, to ensure safety, keep away from people, face, skin and flammable materials. Make sure the flame is completely extinguished after use. Do not let skin come in contact with electronic sparks.

Item Number: 11083



1 98454 11083 0

Gadgets and More
is a trademark of Cam's Wholesale
©2025 Cam's Wholesale

MADE IN CHINA



WARNING: Cancer and reproductive harm. www.P65warnings.ca.gov



RoHS

