


LPB50-24/6227

**Portable 5000mAh
Leatherette Power Cell**



INSTRUCTION MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND

RETAIN FOR FUTURE USE

1

INSTRUCTIONS FOR USE

Charging your Portable Power Bank

- Please use the USB Recharging Cable that is included in your pack. Connect one end of the cable to the Micro USB Input as shown in the figure. The other end should be connected to your computer USB Port or other suitable USB source.
- While charging the Power Bank, Blue LED Light will flash. Once it is fully charged all 4 LED Lights would stay on.
- Note: Before using the product for the first time, please charge the Portable Power Bank for at least 6 hours or until all 4 LED Lights stay on.

Charging your iPhone, Smart Phones or any other USB Rechargeable Devices –

- Please ensure that the Portable Power Bank is fully charged, and then unplugged.
- Please use your device's USB charging Cable that is applicable to charge your device (not included). Connect one end to USB output as shown in the figure and the other end to your device.
- It would start charging your device or press the Power button to start the charging.

Care and maintenance

Read the following recommendations before using the Portable Power Bank.

- Do not expose the battery to liquid, moisture or humidity. This may affect product's internal circuit.
- Do not use abrasive cleaning solvents to clean the device.
- Do not expose the device to extremely high or low temperature as it may cause to destroy the battery or distort certain plastic parts.
- Do not dispose of the device to fire as it may result in an explosion.
- Do not expose the device to contact with sharp objects as this will cause scratches and damage.
- Do not let the device fall down the floor. The internal circuit might get damaged.
- Do not attempt to disassemble the device as it may cause damage.

Product Specifications:

Portable Power Bank with Built-In Rechargeable Battery
 Battery Capacity: 5000mAh
 Output: DC 5V – 1A/2.1A (Max)
 Input: DC 5V – 1A (Max)
 Dimensions: 4-1/2"x2-5/16"x1/2"
 Weight: 4.0 oz
 Built-In Over-charge protection

4

Thank you for using Soundlogic / XT Portable 5000mAh Leatherette Power Cell. This product is universal, portable and chargeable power source which is designed to charge various mobile phones and other USB rechargeable products, such as iPhones, iPad, Samsung, HTC, Nokia, Sony PSP, Tablets, etc.

Getting Started

- Remove the product from the box.
- Remove any packaging from the product.
- Please retain all packaging after you have checked and counted all the parts and the contents against the list.

Package Contents

- Portable 5000mAh Leatherette Power Cell
- USB Recharging Cable
- Instruction Manual

Key Features

- Portable Rechargeable Power Bank – capacity 5000mAh.
- Connects to your iPod, iPhone, iPad, other Smart phones, tablets and other USB rechargeable devices to recharge the battery. Charges 2 devices at a time.
- Power Bank recharges via USB connection of your computer or other USB power source.
- Fits in your pocket, purse or briefcase for travelling purposes.
- Battery Level Indicators - Short press the Power button to see.
- Output port – USB 5V 1A/2.1A

Safety Instructions

- Keep the unit away from heat sources, direct sunlight, humidity, water or any other form of liquid.
- Do not operate the unit if it has been wet or moist to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not use the unit with wet hands.
- Keep the unit free from dust, lint etc.
- Do not use this unit for anything other than its intended use.
- Keep the unit out of reach of children.
- This unit is not a toy.

2

TROUBLESHOOTING

Problem	Solution
Power Indicator does not light up when charging the Portable Power Bank	Please ensure if USB Charging Cable and Power Source is connected properly. Please ensure that your Computer is Turned On.
Portable Power Bank does not charge device once connected	Please ensure if USB Charging Cable is well-connected.

FCC Instructions

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer warranty.

Our product warranty is limited only to the USB Portable Power Supply itself, when used normally in accordance with the operating instructions and the system environment. Therefore, Customer acknowledges and agrees that: Midwest is Trading Group is not liable for damage or loss resulting from the use of this product, or for any claim from third party. Midwest Trading Group is not liable

5

IMPORTANT SAFETY INSTRUCTIONS AND WARNINGS

Never charge batteries unattended. When charging batteries you should always remain in constant observation to monitor the charging process and react to potential problems that may occur.

If at any time you witness a battery starting to balloon, swell up, smoke or hot, discontinue charging process immediately, disconnect the battery and observe it in a safe place for approximately 15 minutes. This may cause the battery to leak, and the reaction with air may cause the chemicals to ignite, resulting in fire.

Do not let the device fall down the floor. The internal circuit might get damaged.

We suggest you put the battery in an enclosure to protect it from damages by liquid or dropping from height accidentally.

Never store or charge battery pack in extreme temperatures, since extreme temperature could ignite fire.

Store battery at room temperature between 40 and 80 degrees F for best results


Do not expose battery pack to direct sunlight (heat) for extended periods

Storing battery at temperatures greater than 170 degrees F for extended periods of time (more than 2 hours) may cause damage to battery and possible fire.

Must keep battery pack away from children

Do not attempt to disassemble the device as it may cause damage.

Description of Parts



3

for problems with your Digital Device, cell phone or other hardware arising from the use of this product; the suitability of the product for specific hardware, software, or peripherals; operating conflicts with other installed software; data loss; or other accidental or unavoidable damages. Midwest Trading Group is not liable for financial damages, lost profits, claims from third parties, etc., arising from the use of this product.

WARRANTY DURATION: All materials and workmanship are warranted to the original consumer purchaser for a period of ninety (90) days from the original purchase date.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in USA, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or to units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMERS: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contract or commercial law including but not limited to, negligence, gross negligence, strict liability, breach of warranty and breach of contract.

WARRANTY PERFORMANCE: During the above 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one-month period. No charge will be applicable for such repair or replacement.

SERVICE AND REPAIR: If service is required for this product, you should first contact Midwest Trading Group Customer Service at info@midtradinggroup.com or by calling 1 (866) 815-4714, Monday to Friday 10am to 6pm EST.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment, and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

6