

IDEAWORKS®

personal
mosquito
repeller



IDEAWORKS®

© 2017 Jobar International, Inc.
Carson, CA 90745

JB7944 [031717]

INSTRUCTIONS

BATTERY PRECAUTIONS

- All batteries must be of the same type.
- Do not mix old and new batteries.
- Do not mix alkaline, standard, or rechargeable batteries.
- If battery contents are leaking, discontinue use and discard.
- Remove dead batteries.
- Remove batteries if not in use.
- Make sure to properly dispose dead batteries in accordance with state and local laws.

CAUTION

Choking Hazard small parts.
keep out of reach of children and pets.
Wash hands thoroughly after handling citronell pads.

NOTE:

Although sonic sound cannot be heard by most people, some individuals will be able to hear a low buzzing sound during normal operation.

Slide fan pannel counter-clockwise to open for ventilation. Slide clockwise to close.

Slide button up to turn fan ON. Fan will blow a distinctive scent that will repel mosquitos. Effective range: 15 – 30 square meters.

Optional: Use the clip on the underside of the battery cover to fasten the repeller to your belt or to any other source desired.

With your finger nail, lift the white cap off the top and insert 1 citronella pad into the center base. Note: 1 citronella pad can be used up to 15 days. Replace the white cap. Make sure to align the clips on the white cap to the gaps on the center base.

Slide button up to turn sonic waves ON. Sonic waves will transmit from small speaker and repel mosquitos. Effective range: 15-30 square meters.

BATTERY INSTALLATION

Grip the base firmly and turn battery cover counterclockwise to open and insert 2-AAA type batteries according to the polarity (+/-) marked in the battery compartment. Replace battery cover. Note: make sure the parallel line marks on the battery cover are perpendicular to the batteries. It takes a little bit of force to open and close.

