



**Bluetooth
Transmitter
& Car Charger**

MANUAL

Safety Instructions

Please read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, the warranty does not apply.


- Keep these instructions.
- Do not drop, puncture or disassemble this product.
- This product shall not be exposed to dripping or splashing.
- Avoid long exposure to direct sunlight, which may cause damage.
- Exposing this product to open flames may cause explosion.
- Do not use the product in strong magnetic field.
- Use clean, soft cloth to clean. Do not use any corrosive cleaner/oil to clean.
- Keep your attention on the road. Do not operate the controls of this product while driving.

Introduction


Features

- Hands-free call
- Stream music to car audio via FM Transmitter
- AUX line out
- Dual USB charging ports
- USB flash

What's included




Car Charger FM transmitter



Manual

At a Glance




- | | |
|---|------------------------|
| 1 USB charging port \USB flash drive port | 6 BT /USB flash Mode |
| 2 USB charging port | 7 Microphone |
| 3 LCD display | 8 FM |
| 4 ◀/Previous/volume- | 9 ▶/Next /volume+ |
| 5 📞 /Play/Pause/Answer/End | 10 AUX line out |
| | 11 Car charger adapter |


LCD Indicators	Status
bt / FM frequency flashes alternately	NO Bluetooth connected and no flash drive detected
bt / Voltage /FM frequency flashes alternately	Bluetooth connected or flash drive detected
FM frequency flashes	Enter FM mode

Get Started


- 1 Plug Car Charger FM transmitter into your vehicle's socket lighter socket.
- 2 Start your vehicle's engine and the LCD display will flash ON. "HI" will be initially displayed, bt /FM frequency will flash alternately. In case you have completed step 4, you would hear a voice prompt "ready to pair".



- 3 Enable Bluetooth on your smartphone and search for Bluetooth devices available. Select "AA BT Transmitter" and connect. Once successfully connected, FM frequency will be displayed and a voice prompt "pairing succeeded" will be heard.



- ④ Turn on the FM radio on you car audio deck and tune to an unoccupied frequency (white noise). Press FM button on Car Charger FM transmitter until FM frequency flashes. Press (◀▶) until the transmitting frequency matches the frequency selected on your car audio.




Play Music

When the Car Charger FM transmitter is successfully connected with your smartphone, you can play music from your phone. Music can then be streamed to your car audio via FM transmitter. You can also enjoy music that is stored on a USB flash drive.



Play/Pause	Press (⏮)
Previous/Next track	Press (⏪ ⏩)

To further reduce echo and cabin noise on your calls you can connect a 3.5 mm AUX cable (not provided) to AUX line out socket of the Car Charger FM transmitter and AUX IN socket of your car audio system.



Hands-free Call


When the Car Charger FM transmitter is successfully connected with your smartphone, you can enjoy convenient hands-free calls

Answer/End a call	Press (☎)
Reject a call	Press and hold (☎) for 1 second

Charge Your Devices



The Car Charger FM transmitter contains dual USB charging ports .You can charge two devices at the same time with maximum output of 5V/3.1A



Specifications

Specifications are subject to change without notice

DC input :12V-24V
 Power output :5v=3.1Max
 Bluetooth version: V4.2
 Bluetooth transmission distance 10m/393.7 in
 Audio format: mp3. wma. flac. wav
 FM frequency range :87.5-108 MHz
 FM transmission range :2m/78.7 in
 USB file system: FAT, FAT32, exFAT
 Operating temperature range:-4°F to 104°F/20°C to 40°C
 Storage temperature range :-40°F to 185°F/-40°C to 85°C