



**H Y P E<sup>®</sup>**

**DIGITAL SPY GLASSES**  
Operation Manual HY-SGLS

Thank you for purchasing the Digital Spy Glasses. Please read all instructions carefully before using and retain this manual for future use and reference.

### **PACKAGE CONTENTS**

- Digital Spy Glasses
- Zip Case
- USB Charging Cable
- Operation Manual

### **KEY FEATURES**

- Built-in camera
- Captures videos, audio and photos

### **SAFETY INSTRUCTIONS**

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not puncture or harm the exterior surface of the product in any way.

Keep the unit free from dust, lint, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.


This product is not a toy. Keep out of reach of children.



#### **WARNING:**

Do not use with wall chargers that exceed 0.5A output.  
Do not charge over 4 hours.

## DIAGRAM



## SPECIFICATIONS

Video format:	AVI
Video resolution:	720 x 480
Input:	DC-5V 200mAh
Storage support:	Micro SD card
Battery type:	Rechargeable lithium
Supported Memory:	16G micro SD card (Max)
Charging Interface:	USB

## Operating Instructions

### 1. Turning Camera On/Off

- Insert the micro SD card.
- Press the POWER button.
- The blue light will turn on and the device will enter standby mode.
- Press the POWER button until the red light turns off to turn the device off.

### 2. Manual Recording Mode

- In standby mode, press and hold the VIDEO button for 2 seconds.
- The blue light will begin flashing and the device will begin recording video.
- Press the VIDEO button quickly and the device will stop recording video.
- Connect device to a computer to retrieve your .avi format video.

### 3. Taking a Photo

- In standby mode, press the VIDEO/ CAMERA button quickly.
- The blue light flashes once and turns off.
- The device will save a .jpeg file and return to standby mode.

### 4. Connecting to Computer

- Ensure the device is turned on.
- Using the enclosed USB cable, connect the device to a computer
- The computer will recognize the device as a "Removable Disk"
- During the first connection, please wait 30 seconds while the device installs necessary drivers onto your computer. Do not disconnect it during this time.
- After you have reviewed, saved, or deleted any video, right click on the "Removable Disk" and select "Eject."
- Do not disconnect the device from your computer until your device says it is safe to remove

### 5. Charging your Device

Connect your device to a computer or a certified wall charger using the enclosed mini USB cable. During charging, the red LED will remain lit. When the battery is fully recharged, the red LED light will turn off automatically. Charging may take up to 4 hours.

### 6. Setting Time

- Install micro SD card into device.
- Turn off the camera and connect to a computer.
- Open the Removable Disk.
- Select "tag.txt" and open.

Type in the date/time in the following format  
YEAR.MO.DAY - HR:MIN:SEC

Please note, you will need to follow a 24-hour military time format. Below is an example:

"2012.05.01 23:59:59"

The above time string shows the time you want to set. Pay attention to the space between Year/Month/Day and Hours Minutes and Seconds.

## **7. Webcam Usage**

- Connect to computer USB interface using the enclosed cable
- After the device is recognized by your computer as a "Removable Disk," press POWER the button quickly.
- If your computer supports webcam functionality, the device will begin recording as a webcam.
- If your computer does not support this device as a webcam, you may need to download additional software. Please visit "[amcap.en.softonic.com](http://amcap.en.softonic.com)" to download a free software called AMCap that may assist in compatibility. Please note, DGL Group is not responsible for any software or hardware problems resulting from the download and use of AMCap.

## **8. Automatic Shutdown**

- When the device is recording, if power is low, the green LED light will flash 4 times, and the device will automatically shut down to save battery life.
- When the micro SD card's memory is full, the green LED light will flash 4 times, and the device will automatically shut down to save the current file

## **9. Restore Factory Settings**

- If you want to restore your device to factory settings, you can do so by inserting a paper clip into the slot where the RESET button is located and pressing once.

## **FCC STATEMENT**

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

Re-orient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Do not attempt to repair or modify this equipment.

**WARNING:** Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment and invalidate the warranty claim.

#### **WARRANTY INFORMATION**

The condition of this warranty and our responsibilities under this warranty are as follows:

Supplier's warranty is non-transferable. And this warranty is limited to the original purchaser only.

\* You must be able to prove the date of original purchase of the unit with a dated receipt.

\* The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.

\* The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.

\* Specifically exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorates and other accessories.

\* A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassemble.

\* Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.

\* This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations. We offer a warranty on our products in accordance with the following conditions:

1) Hype® products are covered by a 12 month warranty. We will resolve damages or defects on Hype® products free of charge within 12 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 12 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.

2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. Hype® reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.

4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.

5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.

6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory

legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business

Asserting a warranty claim:

1) To make use of the warranty service for hardware issues, you must contact the Hype® Service Center by email at support@dglusa.com

2) Hype® will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to Hype®.

**IMPORTANT:** Hype® will only accept parcels that have an RMA number.

Please observe the following when sending the product:

1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc.) unless the Hype® Service Center specifies otherwise.

2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.

3) You must enclose a copy of the sales slip as proof of purchase.

4) Once Hype® has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

**Service outside of warranty**

Hype® can refuse any service claim made that is not covered by the warranty.

If Hype® agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. Hype® will not accept any packages that have not first been approved by Hype® by means of an (Return Material Authorization).

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.