DYNAMO HAND-CRANK FLASHLIGHT WITH EMERGENCY RADIO AND POWER BANK

- A. ON/OFF FLASHLIGHT BUTTON
- **B. LED FLASHLIGHT**
- C. DC PORT
- D. CHARGING INDICATOR LIGHT
- E. FM RADIO CONTROL BUTTONS
- F. DC/USB CHARGER CABLE
- G. DC/USB CHARGING CABLE
- H. MANUAL POWER HAND CRANK





Operation:

Battery Charging

- 1. Via DC Port (C) Connect the USB charging cord (G) with a 5v wall plug and then insert the other end into the Dynamo's DC Port (C). When charging, the indicator light (D) will turn on. When the battery is fully charged, the indicator light will turn off.
- 2. Charge Via Hand Crank (H) Pull the hand crank away from the Dynamo's body. Holding it in one hand, spin the crank handle at an optimal speed of 3 rotations per second. While charging, the indicator light (D)will turn on.

Mobile Charging Devices

- 1. Select an adapter cord for your device.
- 2. Plug the adapter into the charging cord (G) and your device.
- 3. Press the flashlight switch (A); the device will charge automatically.

Radio Play

- 1. Press the ON/OFF button (E) to turn the radio on or off.
- 2. Use the SCAN button (E) to find radio stations in your area. The radio will detect only stations transmitting a strong signal.
- 3. Adjust the volume using the MIN & MAX buttons (E). To turn the volume up, push the MAX button; to turn the volume down, push the MIN button.

Flashlight

- 1. To turn on the flashlight, press the button located on the top of the Dynamo (A).
- 2. To turn off the flashlight, press the button again.

Product Features:

20 Lumen LED Flashlight

Hand Crank for Emergency Charging

USB Battery Charging

Mobile Phone/Device Charger

FM Radio

1000mAh/3.7V Rechargeable Lithium Battery

Full Charging Time via USB - 3-4 Hours

Light/Radio Battery Life - Up to 10 Hours

1 Minute of Cranking Time = 10 Minutes of Illumination

Dimensions: 6"x2 1/8"x1 1/4"

