



Instruction / Manual

DeskRiser


Sit-Stand Desktop Workstation



Adjustable to 5 height positions
165mm—250mm—325mm—385mm—415mm






Operating Steps




- ① Squeeze adjustable levers on each side.
- ② Lift desktop up while levers are squeezed.
- ③ Release levers to lock the desktop at your desired height.

Feature and specifications



A+B=10-88lbs(4.5-40kg)
⚠ CAUTION: DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

Safety

 Warning: Because mounting surface materials can vary widely, it is imperative that you make sure mounting surface is strong enough to handle mounted product and equipment.

 **WARNING**

PINCH POINT
DO NOT place hands on or near support bars. Pinch points are created during lifting and lowering the worksurface. Failure to follow these instructions may result in serious personal injury.





Warning: Impact Hazard! Moving Parts can Crush and Cut.
Raise worksurface to top of vertical adjustment **BEFORE** removing equipment.
Failure to heed this warning may result in serious personal injury and or property damage!



Caution:
Leave enough slack in cable to allow for full range of vertical motion (15" / 38 cm). Failure to heed this warning may result in property damage and or personal injury.



Caution:
Keep monitor and laptop base fully on the worksurface. Allowing any part of base or stand to hang off the edge may result in property damage and or personal injury.



Caution:
Raise worksurface slowly. Raising worksurface too fast may create an unstable situation resulting in property damage and or personal injury.